

Quick Setup

1. Unpack your reader, antennas, cables and other equipment.
2. Connect antennas to the antenna ports of your reader using the supplied cables.
3. Connect the reader to your network with an ethernet cable (not included).
4. Connect the power supply and line cord to the reader and appropriate power source.
5. Download and install the ClearStream RFID application.
 - a. If using our ClearStream RFID Onboard application, follow the included installation instructions for that application within the shortcut menus.
6. Select Registration/Subscription from the Tools menu.
 - a. Enter your subscription login information (or perpetual license registration if applicable).
7. Click the Readers button and click **Add** button to choose your reader type.
8. Enter your reader IP address or hostname. If you do not know this information, you can use the ClearStream RFID **Find Reader** option in the **Add Readers** dialog box.
9. Click **Close** and save your project by clicking Save from the File menu.
10. Click the Start/Stop tab and click the Start All button to start reading tags.

